

Kühl-Gefrierkombination/ Frigorifero-Congelatore/
Frigorifico-Congelador/Fridge-freezer


GEBRAUCHSANWEISUNG

ISTRUZIONI D'USO

INSTRUCCIONES DE USO

INSTRÇÕES DE USO

INSTRUCTION BOOKLET



ERE3600

DE

IT

ES

PT

GB

Safety instructions



Your new fridge/freezer may have other functions compared to your previous one.

Carefully read these instructions to learn how the appliance works and how to care for it. Keep the instruction booklet. It will come in handy if you later sell the cabinet or give it to somebody else.

These warnings are provided in the interests of your safety. Ensure that you understand them all before installing or using the appliance. Your safety is of paramount importance. If you are unsure about any of the meanings or warnings contact the Customer Care Department.

For the User


- The cabinet is intended for keeping foodstuff in a normal household as explained in this instruction booklet.
- Do not keep explosive gases or liquids in the refrigerator or freezer compartment. They may explode and cause injury and material damage.
- Do not let sharp objects come into contact with the refrigerating system on the back of and inside the cabinet. If the refrigerating system is punctured, the cabinet will be damaged and foodstuff inside may spoil.

- Do not keep carbonised drinks or bottles in the freezer compartment. The glass bottles may break.
- The cabinet is heavy. The edges and projecting parts of the cabinet may be sharp. Be careful when moving the cabinet and always use gloves.

Child Safety

- Pay attention so that small children do not gain access to the operating controls or the inside of the cabinet.

Scrapping old cabinets

 The symbol on the product or on its packaging indicates that this product may not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

Contents



Safety instructions 67

Scrapping old cabinets 67

Contents 67

Description of the Appliance 68

Control Panel 68

Before use 69

Using the fridge 69

To start the fridge and set the correct temperature . 69

Temperature inside the fridge 69

Measuring the temperature 69

Switching off 70

Alarms and other features 70

Cabinet interior 70

Using the freezer 71

To start the freezer and set the correct temperature 71

Temperature inside the freezer 72

Switching off 72

Alarms and other features 72

Freezing 73

Suitable storage periods 73

Thawing 73

Cabinet interior 74

Hints and Tips 74

Saving energy 74

Food Storage 74

Protect the environment 74

Maintenance and Cleaning 75

Removing the ventilation grille 75

Cleaning 75

Defrosting the freezer 76

Defrosting the fridge 76

Change of carbon filter 76

To change the light bulb 75

When the appliance is not in use 76

Something Not Working 77

Technical specification 78

Installation 78

Mains Cable 78

Unpacking 79

Remove the transport supports 79

Cleaning 79

Before installing the cabinet 79

Installation of carbon filter 79


Installing the cabinet 80

Door Reversal 81

Electrical connection 81

Description of the Appliance


GB



Model ERE3600

1. Glass shelf
2. Bottle shelf
3. Vegetable drawer
4. Butter compartment
5. Door shelf with Egg holder
6. Egg holder
7. Bottle shelf
8. Freezer plate
9. Freezer drawer
10. Ventilation grille
11. Grid
12. Bottle- and can holder
13. Quick chill shelf

Control Panel



A. Refrigerator power switch

Switches the refrigerator on and off.

B. Temperature display

Shows the average temperature inside the refrigerator.

C. Temperature adjustment button/thermostat

Used to set the temperature in the refrigerator.

D. QUICK CHILL button

Used to switch the Quick Chill feature on and off.

E. Yellow indicator lamp

Lights when Quick Chill is operating.

F. Freezer power switch

Switches the freezer on and off.

G. Temperature display

Shows the highest temperature inside the freezer.

H. Temperature adjustment button/thermostat

Used to set the temperature in the freezer.

I. FAST FREEZE button

Used to switch the Fast Freeze feature on and off.

J. Yellow indicator lamp

Lights when Fast Freeze is operating.

K. Alarm shut-off button

Used to turn the audible alarm off.

L. Red warning lamp

Flashes when one of the alarms in the cabinet has been triggered.

Before use


GB

Position and clean the cabinet as explained in the section "Installation".

Check that the drain hose at the rear of the cabinet discharges into the drip tray.



Before inserting the power plug into the outlet and switching on the cabinet for the first time, leave it standing upright for about 4 hours. Otherwise the compressor may sustain damage. This time will allow the oil sufficient time to return to the compressor.



Using the fridge

GB

To start the fridge and set the correct temperature

Switching on:

Switch on the fridge by pressing the power switch.

Setting the temperature

Press the buttons until the desired temperature flashes in the temperature display (The temperature can be set between +2°C and +8°C.)

"+" raises the temperature.



"-" lowers the temperature.

Once set, the temperature display shows "-" until the temperature inside the fridge reaches +9°C or below.

Allow the cabinet to run for a period of 24 hours whenever the temperature setting is changed. This will allow the temperature to stabilise inside the cabinet.

It is not necessary to reset the temperature when the cabinet is switched on after it has been out of use.

The thermostat recalls the previously set temperature.




Temperature inside the fridge

A suitable temperature inside the fridge is approx. +5°C. Storage temperature in the cabinet is even on all of the shelf levels.


Measuring the temperature

If the temperature is measured using a standard, single thermometer, this should be put in a glass of water centrally placed inside the cabinet. This will reflect the temperature inside the food products. Do not place the thermometer hanging or lying directly on the shelf.



Hints:

- Distribute foodstuffs to allow cold air to circulate freely between the products.
- Also never put warm products into the cabinet. Wait until they have cooled down.
- Cover all foods properly.



Switching off

Switch off the cabinet by pressing the power switch. Keep the button pressed for approx. 1 second.



Power to the cabinet is completely interrupted only when the power plug is disconnected.

Alarms and other features

Door open alarm

If the fridge door remains open for more than 5 minutes, the red warning lamp starts flashing and an audible alarm sounds.

To switch off the alarm:

Press the "alarm shut-off button". The red warning lamp goes out when the door is closed.

Quick chill

This function has two usage areas. One area in connection with cans / bottles being quickly chilled on the quick chill shelf, and the other in connection with large amounts of food at room temperature being placed on the shelf.

Chilling of cans/bottles:

When groceries are placed on the shelf (see under section; Quick chill shelf) the air regulator should be turned to its maximum position, then press the Quick chill button.

This will be indicated in the symbol window with a "C" and by the yellow lamp being lit.

Chilling of warm groceries:

This function is used in connection with large amounts of groceries at room temperature being placed in the fridge. Pressing the Quick chill button starts this function.

This will be indicated in the symbol window with a "C" and by the yellow lamp being lit.

When this function has been activated forced air will chill the groceries, and the temperature in the cabinet reset to +2°C. After 6 hours the Quick chill automatically shuts off and the temperature gradually goes back to its normal setting.

Carbon filter's function:

The built-in carbon filter means that strong smelling groceries can be placed near other groceries without affecting their taste or aroma.







Cabinet interior

The shelves and door compartments are removable and can easily be re-arranged.

Certain shelves must be lifted up by the rear edge to enable them to be removed.

The bottom compartment in the door, the divider and the cover over drawer must not be moved as it has an impact on the air circulation.

Shelves with a raised edge should be placed with the raised edge facing the rear wall of the cabinet.



The vegetable drawer has two moveable partitions with five different choices in order to separate different vegetables.

The vegetable drawer has a removable ventilation edging to increase the circulation of air and reduce the risk of condensation.

Quick chill shelf:

The lower Quick chill shelf can be placed in one of the upper grooves. To maintain the best performance the shelf should be placed in the second groove from the top.

Bottle- and can holder

The side of the bottle and can holder is moveable to enable a more flexible placement of cans and bottles in front of the grid. To allow the holder to be moved easier, when moving sideways, press the shelf backwards.

During chilling of cans or bottles the article should be centrally placed in front of the grid to obtain the best chilling effect.






The bottle support can be pulled out when chilling larger bottles.

For a description of this functions start and stop, see under heading Quick Chill.

Dismantling of the bottle- and can holder.

Take out the Quick Chill shelf with holder from the cabinet.

To loosen the holder from the shelf, bend the hooks/brackets that surround the backside of the shelf.



Using the freezer



To start the freezer and set the correct temperature

Switching on:

Switch on the freezer by pressing the power switch.

The alarm sounds if the temperature inside the freezer reaches room temperature. Turn off the alarm by pressing the switch-off button.

Setting the temperature

Press the buttons until the desired temperature blinks on the temperature display. (The temperature can be set between -15°C and -24°C.)




"+" increases the temperature.

"-" decreases the temperature.

Once set, the temperature display shows the current temperature inside the freezer.

Allow the cabinet to run for a period of 24 hours whenever the temperature setting is changed. This will allow the temperature to stabilise inside the cabinet.

It is not necessary to reset the temperature when the cabinet is switched on after it has been out of use. The thermostat recalls the previously set temperature.



Temperature inside the freezer

To ensure that foodstuff will keep for a long time, be sure that the temperature inside the freezer is -18°C or below. Please note, however, that the energy consumption increases as the temperature decreases.


The built-in temperature display shows the warmest temperature inside the freezer. If the temperature is measured using a thermometer, put it between the products since this will reflect the real temperature in the frozen products. It is normal that the built-in temperature display shows a temperature slightly above that measured in other ways.

Switching off

Switch off the cabinet by pressing the power switch. Keep the button pressed for approx. 1 second.



Power to the cabinet is completely interrupted only when the power plug is disconnected.




Alarms and other features

Door open alarm

If the door remains open for more than about 1,5 minute, the red indicator lamp starts flashing and an audible alarm sounds.

To switch off the alarm:

Press the alarm shut-off button. As long as the door remains open, the audible alarm will sound anew at 1-minute intervals. The red indicator lamp goes out when the door is closed.



Temperature alarm

If the temperature rises above -12°C , the red warning lamp flashes and an audible alarm sounds. The temperature display will then start to flash.

To switch off the alarm:

Press the alarm shut-off button to switch off the audible alarm. The temperature display will stop flashing.

The red warning lamp goes out when the temperature inside the freezer again falls below -11°C .



Find out what caused the alarm. See the chapter "Something not working".

Temperature memory

The temperature memory shows when an alarm has been triggered in the cabinet.

The temperature memory operates as follows:

When the temperature inside the freezer again falls below -11°C the audible alarm stops. The temperature display and the red warning lamp will flash to indicate that an alarm was triggered. When the alarm shut-off button is pressed, the display then displays the warmest temperature inside the cabinet during the alarm phase and the display stops flashing. By referring to the temperature display indication, it is possible to decide whether or not to discard the products inside the freezer.



At about -12°C:

Most food products can be immediately re-frozen. Ice cream is especially sensitive to temperature changes and should be consumed as soon as possible.



At -9° - -2°C:

Food products should be prepared (cooked) prior to eating or re-freezing them.

However, always check the quality of the food yourself to determine if it can be frozen or if it must be discarded.

Freezing

Press the fast freeze button approx. 24 hours prior to placing the food in the freezer.

You need not press the fast-freeze button when freezing smaller quantities of food during any 24-hour period.

Fast freeze is automatically switched off approx 50 hours after the button has been pressed.

Fast freeze can be discontinued by pressing the fast freeze button once again.

The yellow fast freeze lamp remains lit as long as the fast freeze button is engaged.

"A" (ACTION FREEZE) is displayed in the temperature display.

Practical advice on freezing



- When freezing products, use the top shelf, and if necessary the shelf beneath as this is the coldest part.
- Place the foods directly on the freezer shelves.
- Spread out the products as much as possible to allow air to circulate between them.
- Do not place food products which are to be frozen directly against other frozen food. The heat from the unfrozen food may cause the frozen food to thaw on the surface.
- Once frozen, re-arrange the products and put them as close as possible to each other. The food will then stay cold longer in the event of a power failure.
- Do not freeze too much food at the same time. The freezing capacity of the unit is indicated in the specifications section.

Suitable storage periods

Food purchased in frozen condition: Follow the advice on the maximum storage period indicated on the packaging.

Fresh food frozen at home:

Fatty and salty food should not be kept frozen for more than three months. Cooked food and low-fat food may be kept up to about six months. Lean food and berries can be kept for approximately one year.



Check that the cabinet is operating and keeps the set temperature one day after switching it on for the first time. Only after then should the freezer be used to freeze fresh foodstuff.

Thawing

It is best to thaw foods in refrigerator. Place the foodstuff on a plate with a raised edge to prevent liquids from running out. To quickly thaw food, place it in room temperature or in cold water. When using a microwave oven to thaw foodstuff, follow the manufacturer's instructions.

Cabinet interior

Freezer drawers

The freezer drawers make it possible to quickly and easily find the food package you want. To gain space, the drawers can be removed and the products can be put directly on the shelves. On all shelves, except the top shelf, it is possible to place products that protrude 20 mm from the front edge. This allows maximum use of the available space.

Do not remove the bottom drawer. It is required to assure proper air circulation.




Freezer tray

Use the freezer tray to freeze berries and vegetables. After about 4 hours the food will be thoroughly frozen and can then be packaged normally. Food that is frozen in this way will not stick together, enabling you to use only the amount required.

Ice cubes

Fill the ice tray to max. 3/4 since water expands as it freezes. Release the ice cubes by twisting the ice tray.

If ice cubes are kept for a long time, they will dry out and the taste is affected. Thus, throw away old ice cubes and prepare new ones when needed.



GB

Hints and Tips

Saving energy

- Pay careful attention to where the cabinet is placed. See the section "Installation". When installed correctly, the cabinet will consume less energy.
- Try to avoid keeping the door open for long periods, or opening the door too frequently as warm air will enter the cabinet, and cause the compressor to switch on unnecessarily often.
- Ensure there are no obstructions preventing the door from closing properly.
- Thaw frozen food in the fridge. This will ensure safer defrosting of foods and reduce the work of the refrigeration unit
- It is advisable to periodically clean the refrigeration system at the back of the appliance with a duster or vacuum cleaner.
- Always leave warm food to cool down to room temperature before placing in the fridge.
- Food which is to be frozen (when cool) should be placed in the fridge before being transferred to the freezer.
- Avoid unnecessary frosting in the cabinet by packing all foodstuffs into airtight packages before placing them in the freezer.
- Carefully follow the advice on freezing products in the section "Using the freezer". This will prevent wasting energy.
- Do not set the temperature too low in the freezer. A suitable temperature is in the range of -18°C to -20°C .
- Defrost the freezer when the frost layer reaches a thickness of 3-5 mm.
- Make sure the door gasket is complete and always clean.

Food Storage

- To obtain the best results from your appliance, neither hot foods nor liquids which may evaporate, should be placed in the larger compartment.
- Avoid buying frozen food if you can not store it straight away. The use of an insulated container is advisable. When you arrive home place the frozen food in the freezer immediately.
- Ensure that food placed in the freezer is dated and labelled and used in date order to ensure that food is consumed at its best.
Remove suspect food from your refrigerator and clean, refer to cleaning and maintenance.

Protect the environment

- Hand over the cabinet packaging and discarded fridges and freezers to a recycling station. Contact your local council or Environmental Health office for more information.
- Keep foodstuff in re-usable containers. Cut down on disposable material as much as possible.
- When cleaning the cabinet, use a mild washing-up detergent.
- Follow the advice in the section "Saving energy"
- The door gasket and coolant used in this cabinet will not harm the ozone layer.

- All parts in the packaging can be recycled.
- The cabinet has been designed for easy

dismantling and subsequent recycling.

Maintenance and Cleaning

GB


Removing the ventilation grille

The ventilation grille can be removed, e.g. to wash the grille.

Unsnap the ventilation grille by pulling it toward you.

When reassembling the ventilation grid:

First hook at the hitches on the lower edge, then press the grille in position.



Cleaning

Clean the cabinet at regular intervals.



Don't use detergents, abrasive powders, high perfumed cleaning products, wax polishes or cleaning products containing bleach or alcohol when cleaning the product

Disconnect the appliance from electricity supply.

Clean the inside and accessories with warm water and bicarbonate of soda (5ml to 0,5 litre water).

Be careful when cleaning the inside of the cabinet, due to fragile edges.

Rinse and dry thoroughly.

Regularly check the door seals and wipe clean to ensure they are clean and free from debris.

Vegetable drawer.

Pull out drawer.

Lift it over the locks in back on the sliding guides.

Tip drawer downwards and pull it out.

Clean with soft detergent, and rinse with lukewarm water.

Assemble in reverse order.

Wash the outer cabinet with warm soapy water.

Remove the ventilation grille (see the section "Removing the ventilation grille") and vacuum-clean under the cabinet. Once or twice a year dust the condenser (black grille) and the compressor at the back of the appliance, with a brush or vacuum cleaner, as an accumulation of dust will affect the performance of the appliance and cause excessive electricity consumption.





To change the light bulb

The light is switched on automatically when the door is opened. Before replacing the light bulb, disconnect the power plug from the outlet.


Cut the packaging around the bulb socket.

Keep the packaging on to hold the bulb when setting it into the socket. Do not touch the bulb with your bare fingers. Halogen light bulbs are sensitive to grease from the skin.

Use a clear halogen light bulb.



When moving the cabinet, lift it by the front edge to avoid scratching the floor.



Defrosting the freezer

A certain amount of frost will always form on the freezer shelves and around the top compartment. Defrost the freezer when the frost layer reaches a thickness of about 3-5 mm.

Remove the freezer drawers and place them on top of each other by turning every other drawer one half turn. Put insulating material around the drawers, e.g. blankets or newspapers.

The frozen products can also be packed closely together and be kept in a cold location, e.g. in the fridge.

Defrosting can be accelerated by placing bowls with hot water (not boiling) inside the freezer.




Loosen the drainage channel from its resting position and push in according to the illustration and place it in the bottom freezer drawer where water can collect.

Carefully scrape off the ice when it starts to thaw.

Use a wood or plastic scraper. Do not use sharp objects as these may damage the interior.

When all the ice has melted, clean and wipe the cabinet dry, then put the drainage channel back in place.

Switch on the cabinet and replace the frozen foodstuff.



Defrosting the fridge

The fridge is defrosted automatically every time the compressor stops. Frost formation can be prevented by:



- not putting warm foodstuff inside the cabinet.
- avoiding frequently opening the door or keeping it open too long.

Change of carbon filter

To maintain the best performance the carbon filter should be changed once a year with normal usage. New carbon filters can be purchased from your local dealer. The filter is placed behind the grill and can be reached by opening the cover. The cover can be opened by simultaneously pressing the lever on the right of grill (1) and turning the cover outward (2). The carbon filter is then pulled out of its slot (3). The new carbon filter is placed in the existing slot - The filter should be handled carefully so fragments don't loosen from the surface.



Never use a hair drier or other heating appliances to speed up defrosting. Excessive heat may damage the plastic interior, and humidity could enter the electric appliance making it live.



When the appliance is not in use

Disconnect the appliance from electricity supply.

Empty all foods and clean the appliance, leaving the doors ajar to prevent unpleasant smells.

If the cabinet will be kept on, ask somebody to check it once in a while to prevent the food inside from spoiling in case of a power failure.

Something Not Working



Before contacting your local Service Force Centre check the following point:

Problem	Possible cause / Remedy
"□" is displayed in the temperature display.	An error has occurred in measuring the temperature. Call your service representative. (The cooling system will continue to keep food products cold, but temperature adjustment will not be possible.)
Audible alarm + flashing red warning lamp. (It is too warm inside the freezer.)	Switch off the audible alarm by pressing the alarm off button. The audible alarm could have been triggered by: The cabinet having been recently switched on and the temperature still being too high. See the chapter "Switching on and setting the temperature". The door may have been open for so long that the 'door open' alarm was triggered.
It is too warm inside the refrigerator.	Set a lower temperature. Put food products in the right place inside the refrigerator. See the chapter "Temperature inside the refrigerator". Distribute the food products to allow cold air to circulate around them. Make sure that the door is completely closed and that the insulating strip is complete and clean.
It is too cold inside the refrigerator.	Set a warmer temperature.
It is too cold in the "Natura-fresh" zone.	Push the "-" and the "reset" buttons simultaneously about 5 seconds.
Water comes out on the floor.	Place the drain hose at the back of the cabinet above the drain bowl. See the chapter "Before using the cabinet the first time".
It is too warm inside the freezer.	Set a lower temperature. Make sure that the door is completely closed and that the insulating strip is complete and clean. If warm food products have been put inside the freezer, wait for a couple of hours and then check the temperature again. Distribute the food products to allow cold air to circulate around them.
It is too cold inside the freezer.	Set a warmer temperature. Action Freeze could have been switched on. The temperature display shows the highest temperature inside the cabinet. Thus a difference between the temperature indicated on the display and the (average) temperature measured in another way is normal.
Too much frost and ice are produced.	Make sure that the door is completely closed and that the insulating strip is complete and clean.
The compressor operates continuously.	Set a warmer temperature. Make sure that the door is completely closed and that the insulating strip is complete and clean.

The cabinet does not operate at all. Cooling or interior light does not operate. No indicator lamps light.	<p>The cabinet is not switched on.</p> <p>Power does not reach the cabinet. (Try connecting another electrical device to the power outlet.)</p> <p>The power plug is not properly connected.</p> <p>The fuse has blown.</p>
Sound level in cabinet is too high.	<p>The refrigerating system will always produce some sounds. A pulsing sound is heard when coolant is pumped inside the cooling pipes. A ticking sound from the thermostat can be heard when the compressor switches on and off. The sound level varies depending on the operation of the cabinet.</p> <p>If you feel the sound level is incorrect:</p> <p>Make sure the pipes at the back of the cabinet not touch each other. Carefully bend them if they do.</p> <p>If the cushion spacers (between the cabinet wall and pipes) come loose, put them back in place again.</p> <p>Carefully follow the instructions in the chapter "Installing the cabinet".</p>
Power failure	<p>Do not unnecessarily open the cabinet, except when the power cut seems to be long, in which case the food products should be moved to another cabinet that works. If the frozen products are still hard following the power cut, they may be immediately refrozen. If the food products have thawed but are still fresh, they may be used, however they should be prepared before re-freezing or eating them.</p>

Technical specification



Model	ERE3600
Volume Refrigerator Freezer	254 l 87 l
Width	595 mm
Height	2000 mm
Depth	623 mm
Energy consumption	354 kWh/y
Energy class	A
Rated power	150 W
Freezing capacity	14 kg/24 hours

Installation



Mains Cable

Do not remove the power cord by pulling on its lead, particularly when the product is being pulled out of its niche.

- Damage to the cord may cause a short-circuit, fire and/or electric shock.
- In the event of damage to the appliance's main cable, only an authorised service company recommended by the manufacturer or a similarly qualified person may adjust it in order to avoid shock hazard for the user.

Unpacking

Unpack the cabinet and check that it is in good condition and free of any transport damage. Notify the dealer immediately of any damage. Hand the packaging over for recycling. For more information, contact your local city office or the dealer.






Do not allow children to play with the packaging. The plastic film can cause suffocation.

Remove the transport supports

Remove the tape and the transport supports from

- the door sides
- inside the door hinges
- the shelves

Remove the transport support on the glass shelf by pushing the support forward along the edge of the shelf until it stops. Take hold of the rear edge of the glass shelf and pull the shelf and transport support forward until the shelf tilts and the transport support can be removed. Some models are fitted with a silencing pad under the cabinet. Do not remove this pad.



Installation of distance

Assemble the attached distance on the back side of the panel according to the illustration.

Cleaning



Wash the inside of the cabinet using lukewarm water, a mild washing-up detergent and a soft cloth.

Installation of carbon filter

On delivery the carbon filter is placed in a plastic bag to secure the length of life of the carbon filter. The filter should be placed behind the grill before the cabinet is turned on.

The cover can be opened by simultaneously pressing the lever on the right of grill (1) and turning the cover outward (2). The carbon filter is then mounted in the slot found in the back of the cover.

The filter should be handled carefully so fragments don't loosen from the surface.



Installing the cabinet

When two appliances are placed beside each other, the distances enclosed in the plastic wrapping should be glued between the appliances. As shown in the illustration.

Make sure that the power plug is not squashed or damaged by back of the product.

- A damaged power plug may overheat and cause a fire.

Do not place heavy articles or the product itself on the power cord.

- there is a risk of a short circuit and fire.

If the power plug socket is loose, do not insert the power plug.

- there is a risk of electric shock or fire.

To obtain the best performance from the cabinet, ensure:

- the cabinet is placed in a dry, cool place and is not exposed to direct sunlight.
- the cabinet is not placed close to a source of heat, e.g. a cooker or dishwasher.
- the cabinet is level. The cabinet should not lean against any wall. If necessary adjust the feet using the adjustment spanner supplied.
- there is good air circulation around the cabinet and that the air channels below and behind the cabinet are not blocked. The ventilation space above the cabinet must be at least 4 cm.

The ventilation space can either be

- a) directly above the cabinet, or
- b) behind and above the top cupboard. In this case, the space behind the cupboard must be at least 50 mm deep.

Cabinet is placed at a location whose ambient temperature corresponds to the climate classification*, for which the appliance is designed.




* See on the rating plate on the inside of the appliance.

The following table shows which ambient temperature is correct for each climate classification.

Climate classification	for an ambient temperature of
SN	+10°C to +32°C
N	+16°C to +32°C
ST	+18°C to +38°C
T	+18°C to +43°C

If the cabinet is placed in a corner and the side with the hinges facing the wall, the distance between the wall and the cabinet must be at least 230 mm to allow the door to open enough so that the shelves can be removed.

Check that the drain hose at the rear of the cabinet discharges into the drip tray.








The power plug must be accessible after installation of the cabinet.

Door Reversal

1. Close the cabinet and remove the plug from the electrical socket.
2. Remove the ventilation grille. There is a part on the grille that can be removed. Remove and reposition it on the other side.
3. Put the cabinet on a wooden board when it is laid down. Later, when raising the cabinet, it will be easier to grip under the cabinet thanks to the board.
4. Unscrew the lower hinge and remove the lower door. Unscrew the upper hinge pin and remove the upper door.
5. On the centre beam:
Remove the plastic plugs by driving a drift into them and rocking them loose.
Move the centre hinge unit to the other side. Flatten the threads in the holes remaining from the hinges and insert new plastic plugs.
6. On the doors: Change the positions of the door fittings. Put a new plug in the hole on the lower door.
7. Replace the upper door and secure the upper hinge pin.
Replace the lower door. Change the position of the hinge pin of the lower hinge. Then secure the hinge. Remove any play in the door by adjusting the height of the lower hinge with the supplied spanner. Secure with the lock-nut.
8. Raise the cabinet and replace the ventilation grille.
9. To transfer the handle.
Unscrew the screws. Fit the handle onto the opposite side by turning it one half circle. Press the supplied plastic plugs into the holes to which the handle was previously fitted.
10. Put the cabinet in position. Check that the appliance is level. See the section "Positioning the cabinet".

Electrical connection

Connect the cabinet to a grounded electrical outlet.
Voltage: 230 V.
Fuse: 10 A.
Refer to the rating plate on the left inside the cabinet.



www.electrolux.com
www.electrolux.de
www.electrolux.it
www.electrolux.es
www.electrolux.pt
www.electrolux.co.uk



ELECTROLUX HOME PRODUCTS OPERATIONS EUROPE

MARIESTAD DT-AV