


KC-22M FRONT PCB 240CH EXPANDER



**CHANNEL EXPANDER

- 1) SW OFF
 - 2) AM/FM, SCAN SW PUSH -----AF VR SW ON
 - 3) BAND A-B-C-D-E-F 240CH EXPANDER
 - 5) CH9 SW PUSH A-B-C-D-E-F 240CH
 - 6) D BAND STANDARD CB 40CHANNEL
- REMARK: AGEIN 2)--CB BAND 40CHANNEL

**RESET : 1)SW OFF

2)CH9 SW PUSH- VRSW ON- CB BAND 20CH DISPLAY

